

# Bobcat X Quick Start List

The numbers in parentheses ( ) refer to pages in the Bobcat X **User Guide**, published 27 May 2005, manual part number 070-0149-00.

## Installation

- Installing the DVI Board or SDI Board (6)
- Installing the Bobcat X Wall Bracket (9)
- Hanging the Bobcat X on the Wall Bracket (10)
- Connecting Power (12)
- Connecting Picture Sources (14)
- Connecting RS232 Communication (16)

## Configuration

- Quick Start (20), to plug it in and go.

For more precise configuration, look at these detailed instructions:

- Setting up a Bobcat X (22)
- Selecting the Picture (23)
- Adjusting Levels for Digital Computer Sources (26)
- Adjusting Levels for Analog Computer Sources (28)
- Aspect Ratio and Scale Mode (32)
- Adjusting Sharpness (35)
- Position (36)
- Tiling a Display (38)
- Adjusting Color Balance (46)

Cut out and save this card.



*clarity*  
A SONY PICTURE ELECTRONICS COMPANY

See the back of this card.



### Customer Service

**email** [Service@ClarityVisual.com](mailto:Service@ClarityVisual.com)  
**tech support** +1 503 570 4634  
**tech fax** +1 503 570 4657

tech help on web: [www.ClarityVisual.com](http://www.ClarityVisual.com)  
LOGIN button, then blue LOGIN NOW  
Name: tech password: help

Clarity Visual Systems <Superscript>®  
27350 SW 95th Avenue, Suite 3038  
Wilsonville, OR 97070-7708  
**main phone** +1 503 570 0700  
**main fax** +1 503 682 9441  
[www.ClarityVisual.com](http://www.ClarityVisual.com)